


















Dell UltraSharp 52 Thunderbolt Hub monitor
U5226KW/U5226KW WOST
Vodič za brzi početak






































Dell Display and Peripheral Manager:
[Dell.com/support/ddpm](https://dell.com/support/ddpm)



KVM



[Dell.com/support/U5226KW](https://dell.com/support/U5226KW)