










Dell Pro 24 monitor za konferencije


E2426HB

Vodič za brzi početak













2





3







4


















Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dejzi lanac



Dell.com/support/E2426HB

